


Adjustable Relay Rack Shelves



Installation Instructions

Kit P/N:

2USHL-020FULL-20V

2USHL-020FULL-20S

Kit Contents



Assembly Hardware:

- (1) Shelf
- (1) Attachment Flange Right
- (1) Attachment Flange Left
- (2) Equipment Stop/Stiffener Flange
- (4) 10-32 Pan Head Screws
- (4) 12-24 Pan Head Screws
- (6) 8-32 Flat Head Screws
- (4) 10-32 Flat Head Screws

2USHL-020 Installation Instructions


Step 1. Install Attachment Flanges: Determine desired front/rear rack mount position for shelf, install left and right Attachment Flanges accordingly using the 10-32 flat head screws.

Step 2. Mount Equipment Stop/Stiffener Flanges: Stop/Stiffener flanges can be mounted at desired position on top or bottom of shelf to provide support where needed. Use the 8-32 flat head screws. Refer to flange mount options illustration at right.



2USHL-020 Installation Instructions

Step 3. Attach Shelf To Rack: Line up 2 holes in each attachment flange and bolt to rack in desired position using the 10-32 or 12-24 pan head screws.



Warranty Statement

Innovation First, Inc. warrants our products against defects in material and workmanship for a period of one (1) year from the date of purchase. Innovation First, Inc. liability shall be limited to repairing or replacing, at our option, any defective product.